



Ireland Engineering
2086-B Central Ave.
Duarte, CA 91010

Contact: 626-359-7674 (Mon.-Fri. 9-5)
athorum@iemotorsport.com

**Disclaimer. We are not responsible for any damages or injury that is incurred during installation and use of this product. It is understood that the installer is a professional (with applicable ASE certifications) and abides with standard safety protocols while working on automobiles. Any warranty does not cover installer errors. If the installer has any questions they are welcome to call or email. For a complete list of our policies please visit www.iemotorsport.com/policies

Thank you for purchasing our Door Handles/Window Cranks!

These are pretty simple to install, however there is one thing you will need to know. Keep the original bolt for your door handles or window cranks (the pan head with a beveled section)! You will need this for the install.



As shown in the picture install the bolt with the handle off and make it just snug, but not too tight which would spread the prongs too wide for the handle to be put on. This will keep the prongs sturdy enough to handle the pressure from the set screw(s) and keep your handle or crank on. Then just place the handle/crank over the bolt and splines and set the screw(s).

